



I.L. MOTORSPORT

Installation Manual

ND Windblocker transparent

ND0-301103

Open the hood and secure it in the normal way.

Remove the small OEM windblocker by giving it a short pull upwards. (pic 1)



pic 1

Cut out the supplied templates RH and LH.

Now position the templates on the rollbar lining (pic 2 / 3)



pic 2



pic 3

You can now drill the two holes per side in the rollbar lining, please use a Ø10mm drill.

Hint: pre drill the holes with a Ø4-5mm drill before using the Ø10mm drill for optimal result.

Please remove the templates from the rollbar lining, and install the supplied rubber dowels in the holes you just drilled. (pic 4 / 5)



pic 4



pic 5



I.L. MOTORSPORT

Installation Manual

ND Windblocker transparent

ND0-301103

Install the supplied brackets on the transparent windblocker as follows:

Put an 'O' ring on the short screws and slide it through the holes in the windblocker, now put a second 'O' ring onto the protruding screw on the other side. Now you can hold the bracket against the windblocker and attach it by turning the screws. (pic 6 / 7 / 8)



pic 6



pic 7



pic 8



pic 9

Install the rubber protector in the space between the rollbar hoops and on top of the OEM windblocker openings. (pic 9)

Place the windblocker in the rubber protector and attach the windblocker to the rubber dowels with the supplied M5 x 20 screws.





I.L. MOTORSPORT

Installation Manual

ND Windblocker transparent

ND0-301103

Schablone / Template

